



Installing the U Bracket

1. Place the steel bushing and rubber bushing according to the drawing.
2. Use the 3 headless screws to clamp the glass firmly.
3. Insert the aluminum bar and attach armature plate. The aluminum bar can be adjusted so it matches the maglock. NOTE: Do not attach the mounting screw of the armature plate too firmly. Allow floating movement for maximum holding force.

A suitable threadlock should be applied to all fixing screws