


Using the WR-24 Receiver with the AerWave Switch (sold separately)

※ Up to 10 AerWave sensors can be registered with one WR-24 receiver.



※ Make sure to check that all dip switches are in the down (OFF) position before proceeding

1. Registering an AerWave Transmitter with a WR-24 Receiver

- Connect power to the WR-24 receiver.
- Press the Register/Delete button on the AerWave switch for 3 seconds whilst simultaneously pressing the Register I button on the WR-24 receiver.
- ● The red LED will flash on the WR-24 to indicate registration.

2. Deleting an AerWave Transmitter from a WR-24 Receiver

- Connect power to the WR-24 receiver.
- Press the Register / Delete button on the AerWave switch for 3 seconds whilst simultaneously pressing the Delete II button on the WR-24 receiver.
- ● The blue LED will flash on the WR-24 to indicate deletion.

3. Deleting all AerWave Transmitters from a WR-24 Receiver

- Press the Register I button and Delete II button on the WR-24 receiver at the same time for 5 seconds.
- ● The blue LED will flash three times indicating that all registered AerWave transmitters have been deleted.



Using the WR-24 Receiver with the Aer/Wave Switch (sold separately)